(1) Plug the speaker cord connector into the speaker's input terminal,


turn clockwise to lock it in place

(2) Squeeze the lever on the speaker connector with your thumb, then twist the whole connector counterclockwise and pull out.



SPEAKER'S INPUT TERMINALS

AMPLIFIER'S OUTPUT TERMINAL



MATTERS OF SAFETY FIRST

Based on security, before the correct use of this product, please carefully read through the instructions again After reading, please keep it for future reference

< MATTERS OF SAFETY FIRST > is to prevent harm to you or others, property loss, to a variety of pattern identification. The identification and significance of pattern, please fully understand before you continue reading.

WARNING If ignore this logo, misuse, may cause serious injury or even death.

CAUTION If ignore this logo, misuse, may cause damage of the goods or injuries.

(this description refers to the attention of electric shock).

PATTERN REPRESENTATION OF CASES Δ Mark is told to pay attention to the content (with a warning). Pattern of the intermediate drawing attention

Mark is to inform the prohibited acts. Pattern of intermediate describe specific content prohibited. (left picture it means no decomposition).

Mark is inform compulsive behavior, content. Pattern of the intermediate drawing indicates the specific cont (this description refers to the power plug from the socket).

FAULT STATE DO NOT CONTINUE TO USE

In case, continue to use the emergence of smoke, odor, noise and other abnormal condition, will cause fire, electric shock, amplifier fault.Immediately turn off the amplifier, must pull out the power plug from the socket. Confirmation until stopped smoking, to rely on sales shop.

■ DO NOT TRANSFORMATION

Don't alter or decomposition of the products. May result in fire, electric shock.

■ DON NOT PUT IN THE POSITION OF WATER

• This product can not be water, do not get wet. Water, wet may result in fire, electric shock. In the rainy day, snow day, coast, water use should be paid special attention to the.

■ CANNOT BE WATER CONTAINERS ARE PLACED

Don't use a vase, potted plant, glass, cosmetics, pharmaceuticals, container with water and small metal items in the product. The water spill, into the inside of the machine will cause fire, electric shock.

In case of the machine, water, immediately turn off the amplifier, unplug the power plug from the socket, and then contact the sales shop. Continue to use, will cause fire, electric shock.

■ DON NOT BE FOREIGN BODY INTO THE INTERIOR

In case, foreign body into the machine, turn off the amplifier power, unplug the power plug from the socket, and then contact the sales shop Continue to use will cause fire electric shock and then contact the sales shop. Continue to use, will cause fire, electric shock

English

OWNER'S MANUAL

THANK YOU VERY MUCH FOR PURCHASING THIS BMB SPEAKERS SYSTEM. READ THE INSTRUCTION MANUAL CAREFULLY BEFFOR USING THIS SPEAKERS SYSTEM SO THAT YOU CAN OPERATE IT PROPERLY. AFTER YOU HAVE FINISHED, PUT THIS MANUAL

AWAY IN A SAFE PLACE FOR FUTURE REFERENCE.

- This equipment should only be installed by a suitably experienced and qualified person. Is in no way responsible for accidents, injury or damage caused by incorrect installation/setting up, misuse, modification or natural disasters.

 Before wall- or ceiling-mounting this speaker, please make sure that the wall or ceiling is strong enough to support the speaker's weight (12.7 kg). If you are in doubt, please consult a specialist. Serious injury could result if the speaker were to fall.

 Two M10 screw holes are arranged in the top surface of the product for hanging the speaker; both the top and the bottom surface is secured with two M10 mount screws.

 Prior to using hanger and metal accessories with this product, be sure these supporting parts have sufficient strength.

 Avoid installing the speakers in a location exposed to direct sunlight and high levels of humidity. Avoid also locations in the vicinity of stoves and other sources of heat.
- In order to play perfect HF sound, the tweeter should be as high as the ears of listeners, or its acoustic axis should point to human ears.
- For bass, the sound level can be boosted by placing the speaker close to wall (putting it in the corner can boost the bass to the largest extent).

 This speaker system is not magnetically shielded. However, depending on the installation location, color distortion may occur if the speaker system is intalled extremely close to the screen of a television set. If this happens, turn off the television, then turn it on again after 15 to 30 minutes. If the problem persists, place the speaker system away from the television set.

- The rated impedance of this speaker system is 8 Ω. It must be connected to a amplifier which accepts this type of load (miminum and maximum impedances accepted by the amplifier are generally indicated near the loudspeaker outlets: for example "4 Ω -16 Ω" or "6 Ω -16 Ω").
 The maximum input power of these speakers is 500 W. Higher levels of input power may cause dam age to the speaker system and so take every precaution to keep the power down to the specification.
 Any connection or switching on or off of part of the audio system (CD player, tuner etc.) must be carried out after switching off the amplifier or at least with the loudspeaker outlets disconnected (if the amplifier allows). Interference caused by these operations will otherwise reach the speaker and may damage the troble boudspeaker units.
 Do not force a low-power amplifier to produce a high level of sound as harmonic distortion increases rapidly in this situation and may pose a danger to the troble speaker units.
 When boosting particular frequencies using a graphic equaliser or bass and troble correctors, make sure that you do not increase the amplifier volume excessively, as the speaker will be overloaded more quickly.
 Avoid touching the diaphragms and suspensions of speakers units as they are fragile.

- No Be careful not to short the two pins of the free speaker terminal. Doing so could damage the speaker and/or your amplifier.
- After connecting the plugs, pull lightly on the cables to make sure that the ends of the cables are securely connected to the terminals. Poor connections can create noise and interruptions in the sound.

 If the cables' wires happen to be pushed out of the terminals, allowing the wires to come into contact with each other, it places an excessive additional load on the amplifier. This may cause the amplifier to stop functioning, and may even damage the amplifier.
- Switch off the powerof your amplifier. 2. Connect the speaker cables to the speaker connector on the back of the speaker.
- Please put + and in the right place.

 Connect the other ends of the cables to the amplifier's speaker output terminals (for details, refer to your amplifiers instruction manual). Align "+" and "-" of the speaker with those of the left (L) and right (R) sound track of the amplifier, and then connect the speaker with the speaker terminator on the amplifier (please see the figure).

CONNECTING OTHER SPEAKER

- This product can be used with the speakers of this model or this type, or connected with other ancillary speakers. The number of speakers you may connect will vary according to the impedance rating of the amplifier. See the manual that came with your amplifier for more details. The diagram below shows the wiring of two connected speakers.
- Set up and connect the speaker so that the resultant impedance falls within 6-32 Ω.
- Although this Manual allows the resultant impedance to be within 4-32 Ω , 4Ω is not recommended; so please do not use 4Ω as far as possible.

MAINTENANCE OF CABINET

When the cabinets are dirty, clean off the dirt with a soft cloth.
 If the dirt is engrained, moisten a soft cloth in cold or lukewarm water, wring it out, and then wipe off the dirt. Never use thinners or alcohol since these substances can impair the finish of the cabinet. Also, avoid usinginsecticide and other sprays near the speakers.

BMB may change the materials, manufacturing methods, or design of components, in part, for the purpose of product improvem. These actions are routinely introduced into existing products without notice. Current BMB products may differ in some respects from published descriptions but are equal to or better than the original design specifications unless otherwise noted.

شكرا لكم لشراء هذا المنتجات BMB.

قبل استخدام هذا مكبر الصوت، يرجى قراءة تعليمات الاستخدام للتشغيل الصحيح. و بعد

قراءتها ، يرجى الاحتفاظ بها جيدا للرجوع إليها في المستقبل.

تعليمات الاستخدام

Arabic

- 🌒 يتم تثبيت هذا المنتج من قبل الشخص نو الخبرة المناسبة و مؤهلات التثبيت, و الشركة لا يتحمل كل المسؤولية عن الحادثة أو الإصبابة أو الاضرار ذات الصلة الناجمة عن لتركيب أو الإعداد غير الصحيح أو سوء الاستخدام أو التغيير أو كارثة طبيعية.
- عند تثنيت المنتج على الجدار أو السنف ، يرجى التأكد من ما إذا كانت توجد القوة الكافية في الجدار أو السفف التي يمكن أن تدعم تعاما على وزن المنتجات (12.7 كج). و إذا
 كنت في شك، يرجى التشاور مع الخبراء. في حالة سقوط المنتجان، قد يؤدي إلى خطر الإصابة الكبيرة.
 - ورجد في السفح الخاري برخيان بنوغ 100 تتطرق جهاز مكبر الصوت، ورجد في كلا السفح الطوي والسفل للسنتج برخيان بنوع M10.
 قبل استخدام الحامل والملحقات المعدنية مع هذا المنتج، برجي تأكيد ما إذا كانت هذه الأجزاء الداعمة تتمتع يقوة كالفية.
- لا تغم بتثبیت مکبر الصوت فی بینة ضرء الشمس المباشر أو البینة الرطیة چدا . لا تغم بتثبیته بالقرب من موقد أو غیرها من مصدر الحرارة.
 من اجل إعادة إنتاج صوت عالى التردد بشكل مثاني، یجب أن یکون مکبر الصوت ذو التردد العالى في نفس مستوي ارتفاع أندي المستمع، أو یجب توجهه محور الصوت المکبر الصوت إلى موضع الأنن.
- 🗨 بالنسبة إلى الصوت بالتردد المنخفض، يمكن تحسين مستوى الصوت بالتردد المنخفض من خلال وضع مكبر الصوت بالقرب من الحائط (ضع مكبر الصوت في زوايا الغرفة لتكبير الصوت بالتردد المنخفض الي
- 🗨 لا هذا المنتج يملك وظيفة التدريع المغناطيسي. إذا يتم وضع الجهاز قريبة جدا من التلفزيون، ألوان التلفزيون ليست واضحة. و إذا حدث هذا، قم بإيقاف تشغيل التلفزيون، ثم يتم

بدء تشغيل التلفزيون بعد 15 إلى 30 دقيقة. و إذا استمرت هذه المشكلة، يتم تحريك مكبر الصوت بعيدا عن جهاز التلفزيون.


- 🔵 المقاومة التقديرية لمكبر الصوت هي 8 أور. و ينبغي اتصاله بمكبر الصوت الذي يقبل هذا الحمل(علامة الحد الأقصى و الحد الأدني من المقاومة المقبولة لمكبر الصوت توجد
- يجب اتصال أو تشغيل أو إيقاف تشغيل النظام السمعي أو جزء منها (مشغل الأقراص المدمجة و الموالف و الخ) في 🗨 ايقاف تشغيل مكبر الصوت أو فصل مأخذ مكبر الصوت على الأقل (إذا كان مكبر الصوت مسموح بها) ، و الآ هذه العملية سوف تؤدي الي تدخل يؤثر على مكبر الصوت و قد
- يؤ دي البي عطل وُحدة مكبر الصوت. لا تقم بتوليد حجم الصوت العالبي لمكبر الصوت بالقوة المنخفضة، و فمي هذه الحالة ، سوف يكون التشوه التوافقي يكون منز ايدا بسرعة و قد يؤدي البي عطل وحدة مكبر الصوت.
- 🌑 عند استخدام معادل الرسومات أو جهاز تصحيح البص و ثلاثة أضعاف لتعزيز التردد المعين، لا تقم بزيادة مفرطة في حجم مكبر الصوت، الا يؤدي إلى التحميل الزائد لمكبر


🔇 في حالة اتصال المنتج بمكبر الصوت، لا يجعل محطات الاتصال الأخرى في الدائرة القصيرة، و الا قد يودي إلى خلل في المنتج أو مكبر الصوت. ♦ بعد الاتصال ، يتم سحب الكابل بلطف للتحقق من أن الاتصال ويكون فعال وموثروق به . قد سُوء الاتصال قد يؤدي الى الصوت المنقطع أو الضوضاء.
 إذا الجزء الأساسي الكابل ينتشر من محطة، قد تلامس بعضيها البعض . وسوف يسبب التحميل الزائد لهذا مكبر الصوت، مما يؤدي الى فشل ايقاف تشغيل مكبر الصوت.

- ، يم ابعت سمين فوه مدير انصوب. 2. يشم توصيل محطات الانتخال لمكبر الصوت و الكابلات، ولاحظ الغرق بين + و . قم تبوصيل الكابلات و محطات الانتاج لمكبر الصوت. (يرجي اتباع تعليمات استخدام مكبر الصوت للحصول علي طرق الاتصال المفصلة.) لمبعدادة فلين مكبر الصوت "-" و "+" مع الفطين "-" و "+" القائين البدري (ع) والبعني (R) لمضخم الطاقة، ثم قم بتوصيل مكبر الصوت بلغراف مكبر الصوت في مضخم الطاقة. (انظر الرحم التخطيطي.) يتم ايقاف تشغيل قوة مكبر الصوت.


- سمح هذا المنتج باستخدام متحد في وقت واحد، ويمكن أيضنا التوصيل بمكررات صوت أخرى من نفس النوع أو النوع المطابق لهذا المنتج.
 وفقا لمقاومة مكير الصوت المختلفة، عدد مكيرات الصوت القابلة للاتصال هو مختلف, و لمزيد من التفاصيل، يرجى الرجوع إلى تعليمات استخدام مكير للصوت.
 - - يبين الرسم البياني التالي كابلات الاتصال عند وجود الأثنين من مكبرات الصوت. قم بإعداد وتوصيل مكبر الصوت بحيث تكون المعاوقة المجمعة في حدود 6 إلى 32 أوم.
 - على الرغم من أن المواصفات تنص على أن يمكن أن المعاوقة المجمعة تكون بين 4 و 32 أوج ومع ذلك، لا نوصبي بإعداد 4 أوم؛ يرجى عدم استخدام إعداد 4 أوم قدر الإمكان
- يرجي استخدام قطعة قماش ناعمة لتنظيف الغبار و الأرساخ.
 يرجي استخدام قطعة قماش ناعمة لتنظيف الغبار و الأرساخ.
 إذا كان مكبر الصوت قذر اجدا ، يرجي استخدام قطعة قماش ناعمة في المذيبات المحايدة المخفقة بالماء 6-5 مرات انتظيفها، و قم يتم استخدام قطعة قماش جافة انتظيفها. و لا يمكن استخدام سائل التجفيف أو البنزين أو المنظفات أو المذيبات الكيميائية الأخرى على مكبر الصوت أو بالقرب منه ، الا يودي الي تلف سطح مكبر الصوت. و بالإضافة إلى ذلك، لا يمكن استخدام المبيدات الحشرية أو البخاخات الأخرى بالقرب من مكبر الصوت.
- ر مسيس لا تقوم BMB بتغيير المواد أو طرق التصنيم أو التصميمات للمكونات جزئها لأغراض تحسين المنتج عادة ما يتم إدخال هذه العمليات في المنتجات الحالية دون إشعار قد تختلف منتجات BMB الحالية عن الأوصاف المنشورة في مجالات معينة، ولكن ما لم يُنص على خلاف ذلك، فهي مساوية لمواصفات التصميم الأصلية أو أفضل منها.

SOUND PRESSURE LEVEL FREQUENCY RESPONSE





APPEARANCE DRAWING



The specifications and design of this product are subject to change without notice, in the interests of improvements.

CAUTION

INSTALLING

 \bigcirc

- Can not be placed in the shaking of the table upper unstable place. Falling down, falling down can lead to
- Move the product, do not hand grasping the iron net, the speaker unit. May cause injury.
- Moving the product, turn off the amplifier, unplug the power plug from the socket, remove the speaker cable and mobile.Or will lead to cable damage, cause fire, electric shock.
- The product is placed on TV, audio equipment, do not move the product. Articles collapse cause injury.

Can not be placed in damp, dusty places. May result in fire, electric shock.

- This product can not be placed over 10kg weight and ratio of large size items. The imbalance will make the goods fall, fall and hurt.
- CAN NOT SET IN THE FOLLOWING AREAS Can not be placed in the food processing machine, humidifier, steam soot place. May result in fire, electric
- ON CONNECTION
- The machine and other audio equipment, television sets and other machine connection, please read carefully the instructions of each machine, Switch off the power supply, follow the instructions.
- NOTE AT WHEN USING
 - Switch on the power set the volume to a minimum. All of a sudden loud noise can cause hearing impairment.

Please don't sit on or suspended in the loudspeaker. Special attention should be paid to the child. Collapse,

- Don't use long time voice distortion under the state. The speaker fever will cause fire
- 0 Cash card, disk with magnetic products do not close. The speaker magnetic will affect the products, the use

damage can result in injury

Chinese

使用说明书

感谢惠购此款 BMB 产品。 使用此扬声器之前,请仔细阅读使用说明书,以便正确操作。 通读完毕后,请妥善保存,以备日后参考。

- 本制品只限于有适当的经验,持有安装资格的人员进行安装。对于不正确安装或设置、误用、改造或由天灾所带来的事故、受伤或者有关的损坏,恕难
- 在安装本制品干墙壁或天花板之前,请先确认墙壁或天花板的强度是否能充分支撑本制品的质量(12.7kg)。如有疑问请与专家商量。若本制品有掉落的

- 仕安架本制品于福室或大化放之削, 消元網从電電或大化放的強度接合能尤が文棒本制品的质量 (12.7 kg)。如何契问算情况、会有导致受大伤的危险。 制品质面有2个M10螺丝孔用于吊挂扬声器。顶面与地面都是2个M10螺丝。 在与本制品—起使用用尽,金属配件之前,请完确定。 请不要将扬声器安装在阳光直射或非常潮湿的环境中。也不要安装在火炉或其它热源附近。 为了完美再现高频声音,高音扬声器应位于收听者耳朵齐高的高度。或将扬声器声轴指向人耳位置。 对于低音,可以通过将扬声器靠近温键放置未端强低音声级、(将扬声器放置于房间角落时可以最大程度地增强低音)。 ● 本制品不具备磁屏蔽功能。如果扬声器和电视机靠得太近,则电视机的色彩可能会模糊。如果出现这种情况,请关闭电视机,然后 15~30 分钟后重新开

启。如果此问题仍然存在,请将扬声器远离电视机放置。 使用前

- 16 G[→])。

 此扬声器的最大输入功率为 500 瓦,输入功率太高会损坏扬声器。请勿向扬声器施加超过最大功率的功率。

 必须在关闭功放或至少断开扬声器插口(如果功放允许)的情况下,连接、打开或关闭音频系统或其一部分(CD 播放机、调谐器等)。否则,这些操作导致的干扰将影响到扬声器并可能损坏扬声器单元。

 请勿强行使低功率功放产生高音量声音,在这种情况下,谐波失真会迅速加剧,并可能损坏扬声器单元。

 使用图形均衡器或低音、高音校正器等增强特定频率时,请勿过度调高功放的音量,否则扬声器将快速过载。

 请勿触摸扬声器单元的振动膜和悬挂系统。因其较易破损,请勿触摸。

- ◇ 本制品与功放连接的状态下,切勿短路其余的接线端子。否则可能导致本制品或功放产生故障。◇ 连接后,轻轻地拉一下电缆,确认是否切实可靠地连接。连接不良可能会发生断续音或噪音。
- 如果电缆的芯线从端子中散出,可能会互相碰触。这会造成功放超负荷而引起功放停止运行的故障。
- 关闭功放的电源。 连接扬声器输入端子与电缆线。注意区分 + 和 -。 连接电缆线与功放的扬声器输出端子。(详细连接方法请遵从功放的使用说明书。) 让扬声器的 极和 极对准功放左(L)、右(R)声道的 极和 极,然后将扬声器与功放上的扬声器端子相连。(请参见示意图。) ■ 本制品允许多只同时使用、也可以和本制品相同类型或配套类型其他扬声器混合连接。
- 根据功放的额定阻抗不同,可连接的扬声器个数也不同。详细情况请参照功放的使用说明书。下图表示连接 2 个扬声器时的接线。
- 设置并连接扬声器使合成阻抗介于6至32Ω范围内。 工思: 虽然说明书规定合成阻抗可以在 4 到 32 Ω 之间。但是,不推荐采用 4 Ω 设置;请尽可能不要采用 4 Ω 设置。

音箱维护

- 加果音報非常脏,请使用縣有使用 5-6 倍的水稀釋过的中性溶剂的软布刷拭,然后再使用干燥的布刷拭。请勿在音箱上或附近使用稀释剂、汽油、清洁剂或其它化学溶剂,否则可能会损坏音箱表面。另外,请勿在扬声器附近使用杀虫剂或其它喷剂。
- 注意 BMB 可能会部分地出于产品改进的目的而更改组件的材料、制造方法或设计。 这些操作通常会被引入现有产品,恕不另行通知。 当前的 BMB 产品可能在 某些方面与已发布的描述有所不同,但除非另有说明,否则等于或忧于原始设计规格。

Korean

사용 설명서

BMB 제품을 구입해 주셔서 감사합니다 . 이 스피커 를 사용하기 전에 제품의 적절한 작동을 위해 사용 설명서를 자세하게 읽어 보시기 바랍니다 . 나중에 참조 할 수 있도록 잘 보관 하십시오 .

- 이 제품은 적절한 경험을 보유하고 소정 설치 자격을 가진 작업자만 설치가 가능합니다. 부적절한 설치 또는 설정, 잘못된 사용, 개조 또는 자연 재해로 발생되는 사고, 상해 및 관련된 제품 손해 등 일체 책임을 부담하지 않습니다.

 백이나 천장에 제품을 설치할 경우, 백이나 천장의 강도가 충분히 제품 무게 (12.7 kg) 에 견딜수 있는지 확인하십시오. 의문이 있을 경우, 전문가 에게 문의하십시오. 의물 제품이 추락될 경우, 심각한 부상의 원인이 될수 있습니다.

 제품 뒷면에 M10 나사구멍이 2개 있어 스피커를 갈 수 있으며 뒷면과 아랫만에 M10 나사가 각 두개 있음.

 이 제품의 함께 선반, 금속 액세서리를 사용할 경우, 스탠드 자재가 충분한 강도를 확보할수 있는지를 우선 확인하시기 바랍니다.

 직사광선이나 습기가 많은 환경에서 스피커를 설치하지 마십시오. 스토브 또는 기타 열 근원 근처에 제품을 설치하지 마십시오.

 트위터 사문드의 완벽한 재생을 위하여 트위터 스피커는 청취자의 귀 높이에 해당되는 위치에 설치되거나 스피커가 청취자의 귀를 향해 있도록 해야합니다.

- 합니다. 베이스의 경우, 스피커를 벽과 가까운 위치에 설치하면 베이스의 음압레벨을 극대화할수 있습니다(스피커를 방 구석 위치에 설치하면 베이스를
- 이 제품은 자기 차폐 기능이 없습니다 . 스피커와 TV 를 너무 가까이 접근시키지 마십시오 , TV 색상이 흐려질수 있습니다 . 이러할 경우 , TV 전원을 끄 고 15~30 분이 경과된후 다시 켜십시오 . 만일 이 문제가 지속되면 TV 로부터 스피커를 멀리하십시오 .
- 🌒 이 스피커의 정격 임피던스 값은 8 Ω입니다. 반드시 상응한 로드 앰프를 연결해야 합니다 (앰프 최소 및 최대 임피던스 값은 일반적으로 스피커 단자에
- 표기되어 있습니다 : 예를 들면 , " 4 Ω ~ 16 Ω " 또는 " 6 Ω ~ 16 Ω ".

 이 스피커 최대 입력 파워는 500 w입니다 , 입력 파워가 너무 높을 경우 , 스피커가 파손될수도 있습니다 . 스피커에 인가되는 파워값은 최대
- 파워값을 조과하지 마십시오...

 반드시 앤프를 끄거나 또는 최소한 스피커 잭 (만일 앰프가 허용되는 경우)을 차단할 경우 , 오디오 시스템 또는 일부 (CD 플레이어 , 튜너 등)를 연결하 거나 켜고 고십시오..그렇지 않을 경우 , 이러한 조작으로 발생되는 간섭은 스피커에 영향을 미치게 될뿐만아니라 스피커 유닛이 손상 될 수 있습니다. 강재적으로 자전력 앱프에 높은 볼륨 사온드를 생성하도록 하지 마십시오. 이러한 경우 , 고조파 왜곡이 증가되며 스피커 유닛 순상이 발생될 수 있습니다. 교래픽 이월라이지 또는 저음 , 고음 및 기타 향상된 특정 주파수를 사용할 경우 , 무리하게 앰프 볼륨을 높이지 마십시오 , 그렇지 않을 경우 , 스피커가
- 빨리 과부하될수도 있습니다 . 스피커 유닛의 진동판과 서스펜션 시스템을 만지지 마십시오 . 그렇지 않을 경우 , 손상의 원인이 될수 있습니다 .

앰프 연결

- 이 제품과 앰프를 연결한 상태에서 기타 나머지 결선 단자를 단락시키지 마십시오. 그렇지 않을 경우, 제품이나 앰프의 고장의 원인이 될 수 있습니다.○ 연결한 후, 케이블을 살짝 당겨보고 안정적으로 연결되어 있는지 확인합니다. 연결상태가 불량일 경우, 간헐적인 연결 문제가 발생하거나 또는 잡음이 ○ 만일 케이블 코어를 단자로부터 분산시킬 경우, 서로 접촉이 발생될수도 있습니다. 이러할 경우, 앰프 과부하로 앰프 작동이 정지될수도 있습니다.

별도 스피커 연결

- 본 제품은 여러개를 동시에 사용할수 있으며 본 제품과 동일한 유형 또는 기타 보조적 유형의 스피커와 함께 사용할수 있습니다. 앰프의 정격 임피던스에 따라 연결 가능한 스피커 갯수가 다를수도 있습니다 . 자세한 내용은 앰프 사용 설명서를 참조하십시오 .
- 다음 그림에는 2 개 스피커를 연결할 경우의 결선 상태를 보여주고 있습니다. 스피커를 연결 및 설치하여 합성임피던스 값이 6-32Ω 범위내가 되도록 해야 합니다.

설명서 삼 점격 학성임피던스 값은 4-32Ω이나. 4Ω로 설정하는것을 권장하지 않습니다. 가급적 4Ω을 취하지 말아주세요.

● 먼지를 제거할 경우, 부드러운 천을 사용하십시오. ● 스피커를 청소할 경우, 5-6배 물로 희석된 중성 용매에 적신 부드러운 천으로 닦으십시오. 그 다음으로 마른 천으로 천천히 닦으십시오. 시너 , 가슬린 , 세제 및 기타 화학 용제는 스피커 표면 에 손상을 줄 수 있으므로 스피커 주변에서 상기 화학 약품을 사용하지 마십시오 . 또한 , 스피커 주변에서 살충제 를 사용하지 마십시오.

BMB는 부분적으로 제품개선의 목적으로 부품의 소재, 제조 방법 또는 설계를 변경할 수 있습니다.이런 조작은 통상적으로 기존 제품에 도입되고 별도로 알려드리지 않는 것을 양해해 주시기 바랍니다.현재 BMB 제품은 어떤 측면에서 게시된 설명과 다른 부분이 있을 수 있습니다. 별도의 설명이 없는 한, 원래 설계 규격보다 같거나 우수한다는 것에 해당합니다.